Installation and Operation

CBS ArcSafe®

RSA-159

(For Square D, Class 8198)





1.0 Installation

DANGER!

*Ensure that the switchgear to be remotely operated matches the switchgear discussed on the first page. If the switchgear does not match, please contact CBS ArcSafe® for more information regarding remote switching applications for your particular model.

Step 1: Ensure there are no obstructions around the handle operator for installation as seen in Figure 1.



Figure 1: Ensure the area around the handle operator is clean

Step 2: Slide the RSA-159 unit over the handle operator as shown and ensure that the assembly sits flush with the panel Look over Figure 2 for a visual instruction.



Figure 2: Slide the RSA-159 handle locator over the handle operator on the breaker

Step 4: Engage the magnets (figure 3) located on the side of the RSA-159 to secure the device to the panel. Rotate clockwise to secure the magnet.




Figure 3: Rotate clockwise as directed above to secure the RSA-159 to the breaker

2.0 Opening/Closing the Breaker

Step 1: Open the RSO-I lid by disengaging the two latches on the front of the case.

Step 2: Connect four pin threaded style cable from the RSO-I to the RSA-159.



Figure 4: Inside the RSO-I case

Step 3: Turn the power switch to the ON position.

Step 4: If equipped with the Radio Remote Pendant option, ensure that the green activation key is inserted into the slot on the remote.



Figure 5: RSO-I control panel

Step 5: Ensure that the unit is properly installed on the MCC bucket and connected to the RSO-I as previously described.

Step 6: To close, press "CLOSE".

Step 7: To open, press "TRIP"

ATTENTION

Please ensure that either the batteries on the unit are fully charged or the unit is plugged into AC power.

| RSA-159 Component List | | |
|------------------------|----------------------|--|
| | | CBS ArcSafe® |
| Item | Description | Part Image |
| 1 | RSA Tooling Assembly | IN COMMISSION OF THE PARTY OF T |



CBS ArcSafe, Inc. 2616 Sirius Road Denton, TX 76208

Tel: 940-382-4411 Fax: 940-382-9435

Website: www.CBSArcSafe.com Email: info@CBSArcSafe.com

DANGER!

*Ensure that personnel using this equipment are adequately trained in the operation of the switchgear they are planning to work with; that they are correctly stationed outside the arc flash boundary; and that they comply with all applicable Federal, State, Local, and In-house safety regulations and procedures. Attention should be given to distance, angle, and personal protective equipment (PPE).