




*Distance Is Safety®*

A Group CBS Company

# RSA-11B

For Westinghouse DHP 1200-3000A  
Close Only



**Distance *is* Safety®**

WHAT STANDS  
BETWEEN YOU AND  
ARC-FLASH DANGER?

**WE  
DO.**

2616 Sirius Road | Denton, TX 76208 | (877) 4-SAFETY | [www.cbsarcsafe.com](http://www.cbsarcsafe.com)

Rev. 8/22/2017

## More Products by CBS ArcSafe®

### ***RRS-1 – Universal Remote Racking System (Rotary)***

The CBS ArcSafe® RRS-1 is a universal remote racking system capable of remotely installing and removing rotary style draw out circuit breakers without requiring any modification to the existing switchgear. Operation of the simple to use RRS-1 is quite intuitive and requires only minimal setup. When used properly, the RRS-1 allows technicians to remain outside of the arc flash boundary during the potentially dangerous racking operation.

### ***RRS-2 – Universal Remote Racking System (Non-Rotary)***

The CBS ArcSafe® RRS-2 is a universal remote racking system capable of remotely installing and removing non-rotary style draw out circuit breakers without requiring any modification to the existing switchgear. Operation of the simple to use RRS-2 is quite intuitive and requires only minimal setup. When used properly, the RRS-2 allows technicians to remain outside of the arc flash boundary during the potentially hazardous racking operation.

### ***RRS-3 – Application Specific Remote Racking System (Rotary And Non-Rotary)***

The CBS ArcSafe® RRS-3 product line is made up of various application specific remote breaker racking devices. Each standalone system allows service personnel to remotely install and remove a particular type of circuit breaker safely while stationed safely outside of the arc flash boundary during the potentially dangerous operation. The lightweight and compact design of the RRS-3 systems makes them ideal for hard to access areas where space is at a premium.

### ***RRS-4 – PLC Based Universal Remote Racking System (Rotary)***

The CBS ArcSafe® RRS-4 universal remote racking system is an updated PLC based version of the best selling RRS-1. The dual mode, source programmable, PLC based control system offers two different operating modes to choose from based on user preference or the application. The RRS-4 is capable of remotely installing and removing rotary style draw out circuit breakers without requiring any modification to the existing switchgear, allowing users to remain outside of the arc flash boundary during the potentially hazardous racking operation.

### ***RSA – Remote Switch Actuator***

The CBS ArcSafe® Remote Switch Actuator (RSA) product line is made up of various application specific remote operating devices. These products allow service personnel to remotely perform all aspects of an operation for a particular type of electrical equipment from outside the arc flash boundary – reducing or eliminating the possibility of serious injury or death resulting from an arc flash.

### ***RSO – Remote Switch Operator***

During a remote operation, the CBS ArcSafe® RSO functions as both the power supply and user interface for the device being remotely operated by the user. When paired with an applicable CBS ArcSafe® device, this portable standalone system allows service personnel to remotely perform a racking or switching procedure from outside the arc flash boundary – reducing or eliminating the possibility of injury or death resulting from an arc flash

Published and distributed by:  
CBS ArcSafe®  
2616 Sirius Road  
Denton, Texas 76208

A division of:  
GroupCBS, Inc.®  
P.O. Box 1557  
Gainesville, Texas 76241

Copyright CBS ArcSafe® 2013

Printed in the United States of America  
Reproduction, adaptation, or translation without prior written permission is prohibited except as is allowed by law.

# 1 Installation

## **DANGER!**

Before servicing any breaker, make sure that it matches the breaker discussed. If the breaker does not match the breaker described above, please call CBS ArcSafe® for more information.

## **ATTENTION!**

The location of certain items such as mimic bus, stickers, and/or placards may interfere with the proper installation of the RSA. Please remove or reposition these items before installing the RSA.

1. Ensure that the breaker is free from any obstruction that may interfere with the proper installation of the RSA.
2. Plate the RSA at a slight angle to the face of the breaker, then align and insert the locator pin on the RSA to the hole in the turning dolly bracket on the front of the breaker.



3. Ensure the motor on the RSA is in a neutral position (straight down between the actuators) before aligning the CLOSE actuator.
4. Next, rotate the RSA into place against the breaker.
5. Ensure the CLOSE actuator aligns properly over the breaker switch.



6. Turn the handles of the twist-lock magnet 180° clockwise to lock the RSA in place
  7. Place the motor control box so that the cord is out of the way of any moving parts.
- The RSA is now ready for remote operation





## 2 Operation

### ATTENTION!

Please ensure that all cables are clear of moving parts. Failure to do so may result in damage to cables and/or actuator.

### ATTENTION!

Please ensure that the batteries to the RSO-I AR are fully charged or that the unit is plugged into AC power.

For detailed instructions on the operation of the RSO-I AR please see the RSO-I AR Manual.

1. Ensure that the RSA is properly installed. See Section 3 for detailed instructions.
2. Plug the RSO-I AR into the motor control box.
3. Exit the arc flash boundary
4. Turn the power switch on the RSO-I AR to the ON position.
5. Ensure that the Auto Retract (AR) function is OFF
6. If the switch is OFF and needs to be ON, press and hold the CLOSE button on the RSO-I AR until the breaker is CLOSED.



## 3 Adjustments

The RSA comes adjusted from the factory to fit most common configurations, and should not need to be adjusted in most cases. However, if adjustments do need to be performed, it is recommended that they be done on de-energized and isolated equipment to prevent possible damage or injury.

### 3.1 Travel Adjustment

The travel length for the actuators may be adjusted slightly to accommodate differences in breaker layout. Because the switch actuators themselves are fixed on the RSA, this is accomplished by adjusting the depth of the actuators.

1. Install the RSA on the face of the switch as described in the Installation section.
2. Loosen the two lock screws on the actuator plate of the RSA, as shown.




3. Slide the actuator plate up or down to position the actuators as desired. They should be positioned so that the switches on the breaker will be closed near the end of the actuator's travel.
4. Re-tighten the screws loosened in Step 2.

### 3.2 Magnet Depth

The depth of the magnet on the RSA can be adjusted to avoid interference with bolts, plackards, and other items mounted to the switchgear door.

1. Loosen the two bolts on the magnet, as shown below.



2. Install the RSA as described in the Installation section.
3. Slide each magnet up or down as required to accommodate any obstructions on the gear door.
4. Re-tighten any loosened bolts.

### 3.3 Magnet Position

The position of the magnet on the RSA can be adjusted to avoid interference with bolts, placards, and other items mounted to the switchgear door.

1. Loosen the two bolts on the magnet plate, as shown below.




2. Install the RSA as described in the Installation section.
3. Slide each along the RSA frame as required to accommodate any obstructions on the gear door.
4. Re-tighten any loosened bolts.



### 3.4 Locator Position

The locator position can be adjusted slightly to accommodate manufacturing differences between breakers.

1. Loosen the bolts on the locator, as indicated below.



2. Install the RSA as described in the Installation section, and slide the locator as required to properly align the switch actuators with the breaker switches.
3. Re-tighten any loosened bolts.



# Notes

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.



*Distance Is Safety®*

A Group CBS Company

RSA-11B  
Installation and Operation

2616 Sirius Road  
Denton, TX 76208  
Tel: 877-4-SAFETY  
Fax: 940-382-9435  
Website: [www.CBSArcSafe.com](http://www.CBSArcSafe.com)  
Email: [info@CBSArcSafe.com](mailto:info@CBSArcSafe.com)

**DANGER!**

Ensure that personnel using this equipment are adequately trained in the operation of the switchgear they are planning to work with; that they are correctly stationed outside the arc flash boundary; and that they comply with all applicable Federal, State, Local, and In-house safety regulations and procedures. Attention should be given to distance, angle, and personal protective equipment (PPE).